RADICA

WOOGIES™

MONSTERS THAT WREAK HAVOC!

Asst. N1698
M7977 / M7978 / M7979 / N1697
For 1 player / Ages 8 and up

INSTRUCTION MANUAL

P/N 823C2000 Rev.A

Create Your Own Monster

Woogies™ is the anti-nurturing virtual pet just for boys. Train your Woogies™ by grunting, farting, burping, tumbling, flipping, and shaking for the ultimate gross-out battle with other Woogies™! The way that you train your Woogies™ determines how your Woogies™ will develop. The more that you train and anti-nurture your Woogies™ the stronger he will be in battle mode. There are multiple game modes for a variety of anti-nurturing antics!

BUTTONS



On/Start/Select – Press the Power button to turn your Woogies™ on. Woogies™ powers on in anti-nurturing mode. Push the Select to enter one of the three modes Taunt, Train or Battle.

Scroll Button (Right Button) – Push the Scroll Button to scroll through the games menu and battle attack choices.

Back Button (Left Button) – In anti-nurturing mode, press the Back Button to enter the Menu.

GROWTH DEVELOPMENT

Taunt – Taunt and Training lead to the development of the Growth Stages. The more you shake, tumble, fart, burp, etc., the faster your monster will grow.

Train – The better you compete in the games, the more powerful your monster will become.

GAME MODES

Now it's time to choose which game you want to play! Playing games adds to the growth of your Woogies™.

MODE 1: Shake – The objective of this game is to continue shaking the Woogies™ until it lets out a Fart. If you stop shaking the Woogies™ too early or too late, an angry animation appears on the screen. If you stop at the correct time, you will receive a happy animation and points. The better you do in the game, the bigger and stronger your monster gets in battle and training.

MODE 2: Shout – The objective of this game is to mimic the sound that the Woogies™ is making. The Woogies™ will make a noise and you have to repeat that noise quickly. If you make the correct action, you will receive a happy animation and points. If you make the wrong action, an angry animation appears on the screen. The better you do in the game, the bigger and stronger your monster gets in battle and training.

MODE 3: Tumble – The objective of this game is to follow the commands that the Woogies™ gives you. You either need to turn your Woogies™ right, left or flip it depending on the commands that you are given. If you follow the commands correctly, a happy animation will appear. If you miss a command, an angry animation will taunt you. The better you do in the game, the bigger and stronger your monster gets in battle and training.

BATTLING

In order to battle, you must have at least 2 Woogies™. Battling is a combination of three attacks (Grunt, Fart or Burp). Each player chooses one of the three attacks for each round of battle. One attack cancels out the others. During each round, you secretly select what monster you want to battle. You then need to line up the IR (put each Woogies™ face to face to establish the connection). Once the IR is linked up correctly, the Woogies™ will then begin to battle. The Woogies™ will battle for three rounds.

After the battle is finished, the winning Woogies™ receives positive feedback on the screen and chooses the battle mode for the next game. The losing Woogies™ receives negative feedback on the screen, then chooses the battle mode for the re-match. Each player will need to line up the IR once again to continue battling. Game play continues until one of the Woogies™ loses all battle points. The stronger you make your monster, the more powerful your attacks will be in battle.

HOW TO PLAY

Turn your Woogies™ on by pressing the **Power Button**. Your Woogies™ will be in anti-nurturing mode when you turn it on. You can stay in this mode to develop your Woogies™ or hit the **Back Button** to go to the main menu.

In the anti-nurturing mode, you can interact with your Woogies™ through verbal (grunting, farting, burping) and physical (tumbling, shaking, flipping) input. The more you interact and anti-nurture your Woogies™ , the faster and stronger he grows. Each input is continually added until your Woogies™ reaches the next growth stage. It takes 40 points to advance to the next growth stage.

The main menu has three choices (**Taunt**, **Train** or **Battle**). You can select which mode by pushing the **Scroll Button** to toggle through the different options. Once you decide which mode you want to play, hit the **Power Button**.

After 60 seconds of inactivity, the unit will fall asleep.

Prepare to start battling!

BATTERY INSTALLATION / REPLACEMENT

This game is powered by three (3) AAA (LR03) batteries.

- Using a screwdriver (not included), loosen the screw until the battery compartment door can be removed.
- Insert three (3) AAA (LR03) batteries as indicated inside the battery compartment.
- Replace the battery compartment door and tighten the screw with a screwdriver. Do not over-tighten.
- Batteries included are for demonstration purposes only.
- For longer life use only alkaline batteries.
- Replace the batteries when the product does not function properly.
- Remove batteries and dispose of them safely.

ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage;

- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of batteries safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

CAUTION

- **Sometimes, a build-up of static electricity (from carpets, etc) may cause the game to stop working. Just reset the game, and it will work again.**
- **In an environment with radio frequency interference, the product may malfunction and require user to reset the product.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Keep these instructions for future reference as they contain important information.

Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities.

6-MONTH LIMITED WARRANTY FOR USA

(This product warranty is valid in the United States and Canada only)

Radica Games Limited warrants this product for a period of 6 months from the original purchase date under normal use against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica Games Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

In the event of a defect covered under this warranty, first call the toll-free number listed below. Many problems can be solved in this manner. If necessary, you will be instructed to return the product, postage prepaid and insured, to the address below. Enclose your name, address, dated sales receipt, and a brief explanation of the defect. Replacement, and return shipment, will be free of charge.

TOLL-FREE NUMBER: **1-800-803-9611.** Hours: 9:00 AM - 7:00 PM Eastern Time; Monday - Friday; 11:00 AM - 5:00 PM; Saturday.

ADDRESS FOR RETURNS: **CONSUMER RELATIONS, 636 GIRARD AVENUE, EAST AURORA, NY 14052.**

IMPORTANT: Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

© 2008 Mattel, Inc. All Rights Reserved.

RADICA USA Ltd., 16650 Westgrove Dr., Suite 500, Addison, TX 75001.
www.radicagames.com Helpline 1.800.803.9611 or service.mattel.com

Retain this address for future reference.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1.800.803.9611.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312.

Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 P.J. Tel:03-78803817, Fax:03-78803867.

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A.
Consumer Relations 1.800.803.9611.

CONSUMER INFORMATION

Need Assistance? Visit **service.mattel.com** or call 1.800.803.9611 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.

SERVICE.MATTEL.COM